

# Hot Glue Reflow, version 1.0


---

By **R. G. Sparber**

Protected by Creative Commons.<sup>1</sup>



A great pair of tools is a hot glue gun and a hot air gun.



Say I want to pot some wires soldered to a connector. These pins are 0.1" apart and that white wire is rather thick. It wouldn't take much bending to get a short.



I start by just getting enough hot glue around the area to cover. I know it looks bad and there are voids. Not to worry.

---

<sup>1</sup> This work is licensed under the Creative Commons Attribution 4.0 International License. To view a copy of this license, visit <http://creativecommons.org/licenses/by/4.0/> or send a letter to Creative Commons, PO Box 1866, Mountain View, CA 94042, USA.



After a few seconds of the hot air gun, the glue reflows and becomes a smooth, evenly coating, mass.

Then just leave it alone until completely cool.

I welcome your comments and questions.

If you wish to be contacted each time I publish an article, email me with just "Article Alias" in the subject line.

Rick Sparber

[Rgsparber.ha@gmail.com](mailto:Rgsparber.ha@gmail.com)

[Rick.Sparber.org](http://Rick.Sparber.org)

